





ADDAC311 ULTRA FLOOR CONTROL

USER'S GUIDE . REV01 April.2022



From Portugal with Love!

Welcome to: ADDAC311 ULTRA FLOOR CONTROL USER'S GUIDE

Revision.01 April.2022

DESCRIPTION

Most musicians use their feet as an extension of their playing, either pushing piano pedals, sustain pedals, guitar pedals...

We find that feet have been underrated while using modulars, in the past we released a series of modules using sustain and expression pedals for triggering or controlling signals to help breaking the ice. While these are small and still usefull for simple uses we wanted to create something more specific this time.

Our new solution features 5 footswitches and 5 inputs for external expression pedals with independent controls for each.

We wanted to save HP rack space and so created an external floor pedal with all the footswitches and controls keeping the module HP to the minimum possible featuring only the 10 outputs and the connector to the external floor pedal.

Features:

8Hp module

External floor pedal

- 3 meters DB25 connector cable (optional)
- 5 Footswitches with 0 +5v Gate outputs and state led monitor
- 5 Expression pedals inputs with -5v +5v CV outputs and 2 state led monitors

Expression Pedals standards, TRS, RTS, TS, what???

There are many expression pedals in the market and although the most common one is the TRS pedal there are 2 other standards: RTS and TS.

All five ADDAC311 inputs expect TRS pedals, if you're looking into buying one choose a TRS pedal.

If you already have other pedals channel 4 features jumpers that can be switched in order to be used with a RTS pedal.

Channel 5 features a jumper that can be switched in order to be used with a TS pedal.


External expression pedals are required for their outputs to work. External expression pedals are not included.

LITRA FLOOR CONTROL
ACOACSTI


F.SW1
F.SW2
F.SW3
F.SW4
PEDAL
CONNECTOR
EXP.2
EXP.3
EXP.3
ADDAC SYSTEM

Tech Specs: 8HP 2.5cm deep 100mA +12V 50mA -12V


ADDAC311 ULTRA FLOOR CONTROL CONTROLS




EXPRESSION PEDAL SIGNAL FLOW DIAGRAM




ADDAC311 ULTRA FLOOR CONTROL MODULE OVERVIEW



ADDAC311 ULTRA FLOOR CONTROL EXTERNAL PEDAL OVERVIEW



ADDAC311 ULTRA FLOOR CONTROL EXTERNAL PEDAL CONTROLS



For feedback, comments or problems please contact us at: addac@addacsystem.com

